

# PCI-1132 Digital Input Acquisition Device

# User Manual

Rev. B

**Smacq**

Beijing Smacq Technology Co., Ltd.

Smacq.com

Smacq.cn

# Statement

## Copyright

©2020 Beijing Smacq Technology Co., Ltd. All rights reserved

No content of this manual may be reproduced, modified or abridged without prior consent and written permission.

## Trademark information

**Smacq** is a registered trademark of Beijing Smacq Technology Co., Ltd.

The names of the other products and companies mentioned in this document are trademarks or trade names of their respective companies.

## Other Disclaimer

- The information provided in this document may be modified and updated in subsequent versions without prior notice.
- Smacq does not provide any warranties, express or implied, for this document as well as the information inside it, including but not limited to implied warranties of the marketable nature of the product and its suitability for a particular purpose.
- There may be a chance that inaccurate descriptions or errors exist in this document. Smacq does not hold any liability for accidents because of the information and deductive functions provided in this manual, as well as the resulting loss of any chance because of the use of this document.
- Smacq reserves the rights to change product specifications, prices, and decide whether to stop the production.

## Contact Us

If you have any questions or need assistance in using this product or this document, please contact us via:

Phone: (+86)10 - 52482802

E-Mail: [service@smacq.com](mailto:service@smacq.com)

Website: <http://www.smacq.com>

<http://www.smacq.cn>

# Safety Requirements



Warning

Only the voltage within the specified range can be connected. Voltage exceeding the specified range may cause damage to the device, and even present a negative impact on personal safety. Check the product specification for detailed reference to the range of voltages that can be connected by each port.



Warning

Do not attempt to operate the device in other ways that are not mentioned in this document. Incorrect use of the device may be dangerous. In the event of device damage, the internal security protection mechanism will also be affected.



Warning

Do not attempt to replace device components or change devices in other ways that are not mentioned in this document. Do not repair the device yourself in the event of a product failure.



Warning

Do not use the device in an environment where an explosion may occur or where flammable flue or gas is present. If you must use the device in this kind of environment, please fit it into a proper case.



Warning

While the device is running, all chassis covers and fill panels need to be closed.



Warning

For equipment with exhaust vents, do not insert foreign objects into the vents or block air circulation in the vents.

# Measurement Categories



Warning

For use in measurement category I (CAT I) only. Do not use in measurement category II/III/IV. Use this device to connect signals or

## Measurement categories Note

Measurement categories I (CAT I) means that measurements are made on a circuit that is not directly connected to the main power supply. For example, a circuit that is not exported from the main power supply, especially a circuit that is exported from a protected (internal) primary power supply, is measured. In the latter case, the instantaneous stress will change. Therefore, the user should be aware of the instantaneous affordability of the device.

Measurement categories II (CAT II) means that measurements are made on a circuit that is directly connected to a low-voltage device. For example, a measurement on household appliances, portable tools and similar equipment.

Measurement categories III (CAT III) means that measurements are made in construction equipment. For example, a measurement on the distribution boards, circuit breakers, wiring (including cables, Busbars, junction boxes, switches, sockets) in fixed equipment and equipment for industrial use and certain other equipment (for example, fixed motors that are permanently connected to fixtures).

Measurement categories IV (CAT IV) means that measurements are made on the source of low-voltage equipment. For example, a measurement on a meter, a major overcurrent protection device, and a pulse control unit.

# Environment

| Temperature       |                               |
|-------------------|-------------------------------|
| Operating         | 0°C ~ 55°C                    |
| Storage           | -40°C ~ 85°C                  |
| Humidity          |                               |
| Operating         | 5%RH ~ 95%RH, no condensation |
| Storage           | 5%RH ~ 95%RH, no condensation |
| Pollution degree  | 2                             |
| Highest elevation | 2000 m                        |

## Pollution degree description

Pollution degree 1: No pollution, or only dry non-conductive pollution. This pollution degree has no effect. For example: a clean room or an air-conditioned office environment.

Pollution degree 2: Generally only dry non-conductive pollution occurs. Temporary conduction can sometimes occur due to condensation. For example: General indoor environment.

Pollution degree 3: Conductive pollution occurs, or dry non-conductive pollution becomes conductive due to condensation. For example, an outdoor sheltered environment.

Pollution degree 4: Permanent conductive pollution caused by conductive dust, rain, or snow. For example: Outdoor places.

## Recycle precautions



**Warning** Some of the substances contained in this product may be harmful to the environment or human health. In order to avoid releasing harmful substances into the environment or endangering human health, it is recommended that appropriate methods be used to recover this product to ensure that most materials can be properly reused or recycled. For information about processing or recycling, please contact your local professional organizations.

# CONTENT

|   |    |
|---|----|
| <i>Statement</i> .....                        | 1  |
| <i>Safety Requirements</i> .....              | 2  |
| <i>Measurement Categories</i> .....           | 3  |
| <i>Environment</i> .....                      | 4  |
| 1. <i>Getting Started</i> .....               | 6  |
| 1.1. Product introduction.....                | 6  |
| 1.2. Function Diagram.....                    | 7  |
| 1.3. Product specifications.....              | 7  |
| 1.4. Product unpacking .....                  | 8  |
| 2. <i>Installation</i> .....                  | 9  |
| 2.1. Connector signal pins distribution ..... | 9  |
| 2.2. Drive installation .....                 | 11 |
| 3. <i>Digital Input (DI)</i> .....            | 16 |
| 3.1. Digital sensitivity .....                | 16 |
| 3.2. Signal acquisition mode .....            | 17 |
| 3.3. Trigger .....                            | 18 |
| 3.4. Counting edge .....                      | 19 |
| 3.5. Interrupt.....                           | 19 |
| 4. <i>Register address mapping</i> .....      | 20 |
| 4.1. DI digital input register .....          | 21 |
| 5. <i>Service and Warranty</i> .....          | 24 |
| 6. <i>Ordering Information</i> .....          | 25 |

# 1. Getting Started

---

This chapter describes the basic functions of PCI-1132 Data Acquisition Device, as well as product specifications and precautions in the process of product unpacking.

## 1.1. Product introduction

---

PCI-1132 data acquisition device is a kind of digital input acquisition device based on PCI bus, and it can be used for digital signal input and acquisition when loaded into a computer. All digital inputs of are isolated from the computer system by optocouplers.

All digital input channels of can be set to interrupt input and execute user-defined programs.

PCI-1132 data acquisition device supports operating in Windows OS, providing standard DLLs and support for mainstream development languages including VC++, VB, C#, LabVIEW, and MATLAB.

### Key Features

- 32 photoelectric isolated digital input interfaces to support continuous and uninterrupted acquisition.
- Digital input supports up to 500kS/s sampling rate.
- The maximum input withstand voltage is  $70V_{DC}$
- Digital input sensitivity can be set
- All 32 input channels can generate interrupt events, and the interrupt enable can be turned on or off independently for each channel.
- Compatible with 32-bit 3.3V/5VPCI bus

## 1.2. Function Diagram

---

Figure 1.1 shows the schematic diagram of PCI-1132 data acquisition device.




Figure 1.1 PCI-1132 data acquisition device functions

## 1.3. Product specifications

---

The following product specification parameters, unless otherwise stated, are acquired at the temperature of 25°C and the humidity of 40%, while the device is turned on for 20 minutes.

### Digital input

|                       |  |
|-----------------------|--|
| Number of channels    | 32   |
| Ground reference      | ISO GND , Isolate from computer            |
| Digital input form    | photoelectric isolation                    |
| Isolation voltage     | 1000VDC                                    |
| Digital input voltage | High level: 3V ~ 70V<br>Low level: 0V ~ 3V |
| Highest sampling rate | 50kS/s                                     |
| Sensitivity           | 20ns ~ 80s                                 |

|                         |   |
|-------------------------|---|
| Timing resolution       | 20 ns   |
| Channel synchronization | Yes   |
| Software FIFO           | 2MPts   |
| Onboard FIFO            | 8192 Pts  |
| Capture mode            | Continuous acquisition mode / OneShot mode / Single point reading |
| Counting edge           | Yes   |
| Counting edge bit width | 32-bit  |

### Bus power requirements

|                              |                             |
|------------------------------|-----------------------------|
| PCI bus                      | compatible with 5V and 3.3V |
| Power supply                 | PCI bus power supply        |
| Typical current without load | 160mA@+5V, typical          |
| Maximum Load                 | 400mA@+5V                   |

## 1.4. Product unpacking

### Precautions

To prevent electrostatic discharge (ESD) from damaging the device, please note the following:

- Please wear a grounding wristband or touch a grounded object first to ensure being grounded.
- Before removing the equipment from the packaging, please first connect the anti-static packaging to the grounded object.
- Do not touch the exposed pins of the connector.
- Place your device in anti-static packaging when you are not using the device.

### Check the packing list

After unpacking the product, follow the packing list in the box, check the host and each attachment individually to ensure that the items in the box are consistent with the packing list.

If you find that any item is missing, please get in touch with us for help as soon as possible.

If you find that the product comes in damaged after unpacking, please get in touch with us as soon as possible. Do not install damaged equipment on your devices.

## 2. Installation

This chapter describes signal connection and drive installation of PCI-1132 data acquisition device.

### 2.1. Connector signal pins distribution




Figure 2.1 Schematic diagram of PCI-1132 digital input acquisition device




Figure 2.2 Signal connector distribution diagram

Table 2.1, Signal pin allocation

| Signal name | Notes  |
|-------------|--|
| DI x        | Digital output X   |
| ISOGND      | The reference ground of digital I/O is isolated from the computer. |

## 2.2. Drive installation

PCI-1132 data acquisition device can be used in Windows 7 and Windows 10, including 32-bit and 64-bit. Here, taking the driver installation in Windows 10 environment as an example, we will introduce how to install the driver of PCI-1132 data acquisition device step by step. The steps of installing drivers in Windows 7 environment are the same as those in Windows 10 environment.

- 1) Open the device manager of Windows operating system, and when the driver is not installed, it is displayed as "PCI Data Capture and Signal Processing Controller", as shown in Figure 2.3 below.




Figure 2.3 Before the driver is installed

- 2) Select "PCI Data Capture and Signal Processing Controller", right-click and select "Update Driver". Select "Browse my computer to find driver software" in the pop-up dialog box, as shown in Figure 2.4 below.




Figure 2.4 Browse my computer for driver software

- 3) Then in the pop-up dialog box, click "Browse" button, locate the operating system version folder corresponding to the driver, and then click "Next", as shown in Figure 2.5.




Figure 2.5 Locate the folder where the driver is located.

- 4) The computer starts to enter the driver installation process. After the installation is successful, the dialog box shown in Figure 2.6 below pops up, and the driver installation is completed.




Figure 2.6 Driver installation is complete.




Figure 2.7 Device Manager after successful driver installation

# 3. Digital Input (DI)

This chapter introduces the related contents of PCI-1132 data acquisition device used for digital signal input. DI is the abbreviation of Digital Input here.

The circuit diagram of digital input is shown in Figure 3.1.




Figure 3.1, digital input circuit Figure

## 3.1. Digital sensitivity

The setting of digital input sensitivity is to filter the input level jitter of unpredictable length, such as the jitter caused by button switch. Sensitivity is set in time units. For example, the default value of digital input sensitivity of PCI-1132 is 20ms, and its function mode is shown in Figure 3.2 below.




Figure 3.2 Schematic diagram of function mode of digital sensitivity

Take the default value of 20ms as an example. When PCI-1132 detects that the level of the actual input port changes, it starts timing. When it reaches 20ms, it takes the current level state of the actual input port as the acquisition result.

## 3.2. Signal acquisition mode

---

PCI-1132 data acquisition device supports the following three acquisition modes when performing DI acquisition:

- Continuous acquisition mode
- Limited collection mode (OneShot mode)
- Single read

The sampling rate of the first two modes adopts hardware timing. The limited number acquisition mode is called OneShot mode.

### Hardware timing

Hardware timing refers to the sampling rate of the sample acquired by DI. It is controlled by the hardware digital signal (DI sampling clock).

### Continuous acquisition mode

The continuous acquisition mode refers to continuous and uninterrupted data acquisition at a set sampling speed.

In the continuous acquisition mode, after the DI acquisition triggers, the acquisition device collects the signal at a fixed sampling speed, buffers it in the FIFO, and continuously uploads the data in the FIFO to the computer memory buffer. The user program only needs to continuously process the data in memory to achieve continuous uninterrupted data collection.

If the user program could not process the data fast enough, the data will gradually fill up the 2M points of storage space in the computer's memory buffer. After filling it up, the new data cannot be written into memory buffer correctly, resulting in data discontinuity.

### Limited number acquisition mode

Limited number of acquisition modes (OneShotmode) refers to one-time acquisition of the set number of collection points at the set sampling speed.

In OneShot mode, after the DI acquisition triggers, the acquisition device will start acquiring set number of data at the set sampling speed and stop the acquisition automatically after. The user program only needs to read the set data amount from the computer memory buffer.



Attention      The number of set collection points cannot exceed 2MPts.

### Single read

Single read refers to reading the status of the current digital input port once. No trigger is required for a single read.

### 3.3. Trigger

---

The PCI-1132 data acquisition device provides rich trigger options. The DI acquisition trigger options are shown in Figure 3.3.




Figure 3.3 DI trigger options

The DI acquisition uses the DiSoftTrig software trigger as the trigger source by default. The DI acquisition can use other trigger sources via software settings to achieve the synchronization of each function.

DiSoftTrig software trigger and Global software trigger are software triggers, which are used to send a command to the acquisition device to initiate device triggering.

#### **Clear Trigger**

Trigger status can be reset to an untriggered state via software settings.

### 3.4. Counting edge

---

Counting edge means that every DI channel can count the edges on the DI input port, each DI channel has a 32-bit counter, and each channel can independently set whether to count the rising edge or the falling edge.

The schematic diagram of rising edge counting principle is shown in Figure 3.4.




Figure 3.4 The schematic diagram of rising edge counting principle



**Attention** Counting edge function is to make counting edge for the collected results after digital input sensitivity filtering.

### 3.5. Interrupt

---

All DI input channels of PCI-1132 can be set as bit interrupt sources, and can also be set as high-level interrupt or low-level interrupt at will.

Through the dll and functions provided by us, users can implement custom interrupt service functions. Please refer to the corresponding routine for detailed usage methods.

## 4. Register address mapping

---

Address mapping should be applied to lower-level programming development. Before that, developers should be familiar with the principles of computer system and PCI interface. Therefore, in the Windows system environment, we recommend developers to use the drivers and dll provided by us to develop the devices.

All registers in the device are 32-bit wide, some registers use all 32-bits, and some registers only use a part of them. The register addresses given in this paper are all offset addresses.

Later, by default, developers are already familiar with the principle of computer system and PCI interface, so the related terms and reading and writing methods will not be described in detail.

### PCI register

| Offset Address | Name                                    | R/W | Explain   |
|----------------|---|-----|---|
| 0x0000         | Interrupt state                         | R/W | Bit-0: DMA completes the interrupt, 1 means an interrupt is generated, and 0 means no interrupt is generated.<br>Bit-1:An interrupt is generated about the DI electrical level, 1 means an interrupt is generated, and 0 means no interrupt is generated.               |
| 0x0004         | Interrupt enable                        | R/W | Bit-0: DMA completes the interrupt enable, 1 means an interrupt is generated, and 0 means no interrupt is generated.<br>Bit-1:An interrupt enable is generated about the DI electrical level, 1 means an interrupt is generated, and 0 means no interrupt is generated. |
| 0x0008         | DMA transfer destination header address | R/W | When the device performs DMA transfer, it corresponds to the first address of the computer memory target.   |
| 0x000C         | DMA transfer length                     | R/W | Actual DMA transfer length, in DWORD.   |
| 0x0010         | DMA transfer counter                    | R/W | Actual DMA transfer length, in DWORD.   |

## 4.1. DI digital input register

| Offset Address | Name                                   | R/W | Explain  |
|----------------|--|-----|--|
| 0x0200         | DiReady                                | R/W | DI function configuration completion flag, 1 means to start waiting for triggering, and 0 means that the configuration has not been completed.   |
| 0x0204         | Di acquisition mode                    | R/W | 0: Software-initiated single point read<br>1. Hardware timing limited number of acquisitions<br>2. Hardware timing continuous acquisition  |
| 0x0208         | Di sampling period                     | R/W | Di acquisition period, in 20ns.<br>Di acquisition actual period = this register value * 20ns   |
| 0x020C         | Di limited number of collection points | R/W | Di collects points for a limited number of times.  |
| 0x0210         | Di acquisition clock source            | R/W | 0: external clock.<br>1: internal clock.   |
| 0x0214         | Di trigger source                      | R/W | See the trigger source chapter later.  |
| 0x0218         | Di single point reading                | R   | Read the current Di status.  |
| 0x021C         | Di interrupt level                     | R/W | Set the level at which Di generates an interrupt. Each bit represents the interrupt level of the corresponding channel, 1 represents the high-level interrupt and 0 represents the low-level interrupt.  |
| 0x0220         | Di interrupt channel                   | R/W | Channels that can generate interrupts. Each bit represents the interrupt level of the corresponding channel, 1 represents the high-level interrupt and 0 represents the low-level interrupt.             |
| 0x0224         | Di sensitivity count value             | R/W | Set the Di sensitivity in 20ns.<br>Di actual sensitivity = this register value * 20ns  |
| 0x0228         | Di counter enable                      | R/W | 1 means to start the counting function, and 0 means to turn it off.  |
| 0x022C         | Di counting edge                       | R/W | Set whether the Di counter is rising edge counting or falling edge counting. Each bit represents the corresponding channel, 1 represents the rising edge count, and 0 represents the falling edge count. |
| 0x0230         | Di0 counter value                      | R/W | R: read the current counter value.<br>W: the counter is cleared.   |
| 0x0234         | Di1 counter value                      | R/W | R: read the current counter value.<br>W: the counter is cleared.   |
| 0x0238         | Di2 counter value                      | R/W | R: read the current counter value.<br>W: the counter is cleared.   |

| Offset Address | Name               | R/W | Explain  |
|----------------|--------------------|-----|--|
| 0x023C         | Di3 counter value  | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0240         | Di4 counter value  | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0244         | Di5 counter value  | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0248         | Di6 counter value  | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x024C         | Di7 counter value  | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0250         | Di8 counter value  | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0254         | Di9 counter value  | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0258         | Di10 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x025C         | Di11 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0260         | Di12 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0264         | Di13 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0268         | Di14 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x026C         | Di15 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0270         | Di16 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0274         | Di17 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0278         | Di18 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x027C         | Di19 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |

| Offset Address | Name               | R/W | Explain  |
|----------------|--------------------|-----|--|
| 0x0280         | Di20 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0284         | Di21 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0288         | Di22 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x028C         | Di23 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0290         | Di24 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0294         | Di25 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x0298         | Di26 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x029C         | Di27 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x02A0         | Di28 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x02A4         | Di29 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x02A8         | Di30 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |
| 0x02AC         | Di31 counter value | R/W | R: read the current counter value.<br>W: the counter is cleared. |

## 5. Service and Warranty

---

Beijing Smacq Technology Co., Ltd. is committed to its products during the warranty period, if the product fails under normal use in warranty, we will repair or replace defected parts for free. Please refer to the warranty explanation in the box for detailed instructions.

In addition to the warranties mentioned in this manual and the warranty note, we do not provide any other warranties, express or implied, including, but not limited to, any implied warranties as to the tradable nature of the product and the suitability of the special purpose.

To get more technical support and service details, or if you have any questions about using this product and this document, you are welcome to contact us:

Phone: (+86)10 - 52482802

E-mail: [service@smacq.com](mailto:service@smacq.com)

Website: <http://www.smacq.com>

<http://www.smacq.cn>

## 6. Ordering Information

---

### Host

| Model    | Notes                          |
|----------|--------------------------------|
| PCI-1132 | 32-DI, Photoelectric isolation |

### Optional accessories

| Model       | Notes                                    |
|-------------|--|
| DB37CB-1.5M | DB37 connecting line, double male, 1.5m. |
| DB37TB      | End board, DIN guide rail installation   |